

Overview of Touch Screen and Switches

Switch operation

This system operates mainly by the switches on the screen. To protect the screen, lightly touch switches on the screen with your finger. When you touch a switch on the screen or on the automatic air conditioning control panel, a beep sounds.

INFORMATION


- *If the system does not respond to a touch of a switch, move your finger away from the screen and then touch it again.*
- *You cannot operate dimmed switches.*
- *Wipe off fingerprints on the surface of the display using a glass cleaning cloth.*
- *The displayed image may become darker and moving images may be slightly distorted when the display is cold.*

- *Under extremely cold conditions, the map may not be displayed and the data input by a user may be deleted. Also, the display may take time to change, and a button on the automatic air conditioning control panel may be harder than usual to depress.*
- *The display may be tinged in purple due to the reflection of sunlight, but this is not a malfunction.*



Symbols, Switches and Buttons

Symbols, Switches and Buttons



Symbols, Switches and Buttons



Changing the route guidance

When you touch this switch, the Change route screen will appear. For details, see page 33.



One-touch registration of marked point

Touch this switch to register the current vehicle position as a marked point. For details, see page 75.



Displaying of points of interest

Icons such as restaurants and hotels, etc. can be displayed on the screen. For details, see page 47.



Zoom in/Zoom out

These switches magnify or reduce the map scale. For details, see page 51.

