

## ***SECTION IV***

---

### **OTHER FUNCTIONS**

Screen adjustment ..... 87

**IV**

## Screen adjustment

You can adjust the brightness or contrast of the screen depending on the brightness of your surroundings. You also can turn the display off.

Push the "DISPLAY" button on the automatic air conditioning control panel to display the "Display" screen.

### INFORMATION

*The display may be tinged in purple due to the reflection of sunlight, but this is not a malfunction.*



#### Contrast and brightness adjustment

##### CONTRAST "+":

Strengthens the contrast of the screen.

##### CONTRAST "-":

Weakens the contrast of the screen.

##### BRIGHTNESS "+": Brightens the screen.

##### BRIGHTNESS "-": Darkens the screen.

The screen turns off when you push the "SCREEN OFF". To turn the display screen back on, push any buttons on the automatic air conditioning control panel such as "INFO", etc. The selected screen appears.



#### Depending on the position of the headlight switch, the screen changes to the day mode or night mode.

To display the screen in the day mode even with the head light switch on, touch "DAY MODE" on the adjustment screen for brightness and contrast control.

However, if the instrument panel light control switch is turned fully to the right, mode switching cannot be done. It remains in the day mode. In this case, "DAY MODE" is not shown on the screen.

If the screen is set in the day mode with the headlight switch turned to on, this condition is memorized in the system even with the engine turned off.